

# CRACKSTITCH®

## INSTALLATION INSTRUCTIONS

### STEP 1:

- For uneven concrete surfaces, grind the surface to level the area.

### STEP 2:

- Lay the stitch perpendicular across the crack
- Mark a line along the length of the stitch approximately 11" long.
- **Crack Stitch Spacing:**
  - 4" Thick Concrete = 8" apart
  - 6" Thick Concrete = 6" apart
  - 8" Thick Concrete = 4.5" apart

### STEP 3:

- Chase crack to minimum of ¼" wide by ½" deep
- Vacuum any remaining dust or debris from area.

### STEP 4:

- Cut a slot minimum 1/8" wide 1" deep at each location (may be cut wider and deeper.)
- Vacuum any remaining dust or debris from area.
- Dry fit the stitch to be sure the entire stitch is below the surface, then remove the stitch.

### STEP 5:

- Fill the slots and crack with adhesive.

### STEP 6:

- Embed the stitch into the slot.
- Trowel the adhesive smooth with the surface.
- Add more adhesive if needed and trowel flush.



Scan QR code to  
watch installation  
video!

## CRACKSTITCH

184 W. 64<sup>th</sup> Street

Holland, MI 49423

Email: [support@crackstitch.com](mailto:support@crackstitch.com)

[www.crackstitch.com](http://www.crackstitch.com)